

Please carefully read and understand the operations manual before utilizing any KRINNER equipment.

KRE20

Step by Step Installation Guide



Step 3

Fit screw head tool to KRE20



Step 4

Fit screw to the screw head tool



Step 5

Flip KRE20 upright placing screw tip into pilot hole



Step 1

Pre drill pilot hole into ground using an auger bit to determine soil conditions**



Step 2

Turn KRE20 upside down resting on the ground



Step 6

Attach stabilizer bar onto KRE20 and brace bar against a stable object or stake placed into the ground. Do not hold the stabilizer bar in arms or attempt to keep it immobile by stepping on it or serious injury could occur during screw installation



Step 7

Make sure KRE20 is set in the OFF position. Plug KRE20 into the electrical supply



Step 8

Hold onto handles of KRE20
Switch machine to gear 1. Turn on KRE20



Step 9

Check level often to ensure screw is going into ground vertically and level



Step 10

With steady downward pressure, screw will slowly rotate into pilot hole. If screw rotation speed slows down significantly switch machine to off. While machine is in off position switch KRE20 to gear 2 and then restart machine for added torque, this gear is slower



Step 11

Be sure to leave approximately 3-6 inches of screw above level ground. Once installed, turn KRE20 switch to off, unplug from electrical source, remove screw head tool from screw head

** Most common soil conditions

- Sandy soil
- Hard compacted soil such as clay; drill down and pull out compacted soil using auger helices, repeat as necessary. If needed add water down hole to loosen and soften the soil
- Rocky soil; Use an auger bit with rock tip to penetrate this type of soil condition

INVENTORY LIST

Please confirm you have received all items listed with your KRE20 rental. If any items are missing, please contact KRINNER and we will arrange to provide you with the necessary items needed to finish your project.

- 1 / 1 KRE20
- 2 / Stabilizer bar
- 3 / Screw head tool you will be installing
- 4 / Quick Start Guide

Link to our KRE20 Installation video



KRINNER
Foundation Systems,
6747 Theall Road, Building A,
Houston Texas 77066,
Phone: +1 877-465-7466
www.krinner.io
info@krinnerfoundations.com

KRINNER
Schraubfundamente GmbH
Passauer Straße 55
D-94342 Straßkirchen
Phone: +49 9424 94 01-80
www.krinner.io
service@krinner.com

By accepting this equipment, you agree that you have read and understand the operating instructions and safety guidelines for this equipment and will comply with them at all times during use.